

GRANITE COMMUNICATIONS, INC.

www.granitecomm.com

203-234-4900

AVT VOICEMAIL OVER RIDE MAIN GREETING

ACCESS ADMINISTRATOR MAILBOX

- 1) From your phone enter your System Administrator mailbox number and security code
- 2) Press 4 to access the System Administrator functions
- 3) Press 6 to change answer mode over ride
- 4) Follow prompts